



# Traverse 540° Large Rescue Belay

UL Certified to NFPA 1983 (2001 Ed) General Use

Passes BCCTR's Belay Competence Drop Test Criteria

- Developed to meet the needs of rescue system belays
- The 540° Rescue Belay is a self-locking device that meets demanding drop-test criteria
- A built-in release lever releases the tension on the belay rope, eliminating the need for a release hitch
- Large 540° rescue belay is designed for use with kernmantle rescue rope from 11.6 mm to 13mm
- Small 540° rescue belay is designed for use with kernmantle rescue rope from 10.6 mm to 11.5 mm
- Weight: 1 lb. 6 oz (624 g). 3Ö MBS: 8,000 lb. (36 kN).

**RR0100 9900** 540° Rescue Belay, Small

**RR01009902** 540° Rescue Belay, Large

**VI3310** Training Video, VHS

**VI3311** Training Video, PAL



## CMC Rescue Steel Locking D Carabiners

UL Classified to NFPA 1983 - General Use.

Manufactured by Omega Pacific

- Designed with auto-locking to provide safety of a 3-stage auto-locking gate that can be easily opened with one hand
- The auto-locking carabiner decreases the possibility of forgetting to lock the gate or that the gate will vibrate unlocked
- The compact size maximizes strength and allows a wide gate opening to fit over most litter rails
- On the screw-lock models, the nut locks against the gate to prevent jamming. Proof tested.

**RR01109999** CMC Rescue Steel Locking D Carabiners





## CMC Pro Series Anchor Straps

UL Classified to NFPA 1983

- The D-ring allows the use of high-strength webbing without compromising carabiner strength. One end is larger so the other end can pass through allowing the strap to be rigged in a Girth Hitch
- Minimum end-to-end 3 sigma MBS: 8,039 lb. (36 kN)
- Length when fully extended: 7 ft./2.1 meters

**RR10249902** CMC ProSeries Anchor Straps



## CMC Pro Series Pick Off Strap

- Created to quickly connect to the victim and then adjust the strap to the best length
- Works well for positioning the victim for a lowering or rappel-based pick off, or for an assisted rappel
- Loop on the end adds a more positive grip when pulling to adjust
- Improves long-term performance, especially where it threads through the buckle
- End is rated at 8,039 lb (36 kN)
- Length when fully extended: 42 inches/107 cm Weight: 13 oz

**RR11069999** CMC ProSeries Pick Off Strap



## Litter Bridle

- Litter bridles are intended for use with any style litter
- Hardware meets NFPA and military specifications
- "O" ring for top tie-in point is rated 134 kN (30,000 lb)
- Parachute buckles used allow independent adjustment to set the best basket angle for patient comfort
- The use of Mil-Spec hardware reduces wear on the webbing
- Rated strength for bridle is 22kN (5,000 lb) / 2,268 kg

**0313897** Hard Eye Litter Bridle

**0313898** Soft Eye Litter Bridle

